

SX SERIES SERVICE PARTS

SX SERIES SERVICE PARTS		SX10	SX10SR	SX12	SX12SR
CONTENTS	DESCRIPTION	PART NUMBER			
3, 4, 5, 6, 7, 8, 9, 10, 11, 12, 16, 45, 46	Control Box Assembly	90-42642	90-42642	90-42642	90-42642
6	Contactora	90-32492	90-32492	90-32492	90-32492
36, 37, 38, 39, 40, 41, 42, 43	Clutch Assembly	90-42657	90-42657	90-42657	90-42657
24, 47, 48	Motor Assembly	90-42648	90-42648	90-42651	90-42651
7, 10	Remote Control Socket	90-42645	90-42645	90-42645	90-42645
9, 27, 28, 29, 32, 47, 48, 49, 50	Small Parts Kit	90-42660	90-42660	90-42660	90-42660
1, 51	Tie Bar & Drum Light	90-41443	90-41443	90-41443	90-41443
N/A	Fairlead, Hawse (Not Shown)	N/A	90-41446	N/A	90-41446
N/A	Fairlead, Roller (Not Shown)	90-32493	N/A	90-32493	N/A
N/A	Hook (Not Shown)	90-42666	90-42666	90-42666	90-42666
N/A	Power Cable Kit (Not Shown)	90-42669	90-42669	90-42669	90-42669
N/A	Remote Control, Wired (Not Shown)	90-42654	90-42654	90-42654	90-42654
N/A	Remote, Wireless Control (Not Shown)	2277R	2277R	2277R	2277R
N/A	Rope, Steel Cable Wire (Not Shown)	90-24576	N/A	90-24576	N/A
N/A	Rope, Synthetic (Not Shown)	N/A	90-24595	N/A	90-24595

ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	1710200-12-1	TIE BAR	1
2	1710200-13	DRUM, SX	1
3	1710200-15-1	LID, CONTROL BOX, SX	1
4	1710200-15-2	DUST COVER, SX	1
5	1710200-15-3	CONTROL BOX BASE, SX	1
6	1710200-15-4	CONTACTOR, 12VDC	1
7	1710200-15-5	SOCKET, REMOTE CONTROL	1
8	1710200-15-6	PIN - DUST COVER	1
9	1710200-15-8	SOCKET SEAL	1
10	1710200-15-12	SCREW, FLAT HEAD M3	2
11	1710200-15-11	SCREW, SOCKET HD M4	4
12	1710200-15-10	SCREW BUTTON HD M4-0.7*8MM	1
13	1710201-15-16 (SX10SR/SX12SR)	WIRELESS RECEIVER SX	1
14	1710201-15-13	NUT, FLANGE SERRATED M8	4
15	1710201-15-3	RECEIVER BOX	1
16	1710200-15-17	INSERT, CONTROL BOX	1
17	1710200-16	SCREW, SOCKET, M8	4
18	4-51-0823	M8 SPRING WASHER	4
19	1710200-20	BADGE SX LOGO	1
20	1710200-21 (SX10/SX10SR) 1712200-20 (SX12/SX12SR)	BADGE SX-10 (SX10/SX10SR) BADGE SX-12 (SX12/SX12SR)	1
21	1710200-22	DRIVE SHAFT	1
22	1710200-11-3	DRUM SUPPORT - MOTOR END	1
23	1710200-11-1	MOTOR HOUSING	1
24	1710200-11-2 (SX10/SX10SR) 1712200-1-12 (SX12/SX12SR)	MOTOR, 12V, 5.5 HP (SX10/SX10SR) MOTOR, 12V, 6.0 HP (SX12/SX12SR)	1
25	1710200-11-4	SCREW, BUTTON HEAD, M5-0.8 X 20MM	4
26	1710200-11-5	WASHER-M5 SPRING	4
27	1710200-11-9	GASKET, DRUM SUP-DRUM	2
28	1710200-11-10	DRUM-BEARING	2
29	1710200-11-8	BRAKE	1
30	1710200-14-2	DRUM SUPPORT, GEAR BOX END	1
31	1710200-14-1	GEAR BOX SX	1
32	1710200-14-7	GASKET, GEARBOX-DRUM SUPPORT	1
33	1710200-14-4	GEAR TRAIN, SX	1
34	1710200-14-10	WASHER, SPRING M6	8
35	1710200-14-3	SCREW, SOCKET HEAD M6	8
36	1710200-14-11	SET SCREW, M6	1
37	1710200-14-5-1	CLUTCH BASE	1
38	1710200-14-5-2	O-RING, 23MM I.D.	1
39	1710200-14-5-3	CLUTCH PIN	1
40	1710200-14-5-4	O-RING, 11MM I.D.	1
41	1710200-14-5-5	SPRING, CLUTCH	1
42	1710200-14-5-6	CLUTCH HANDLE SX	1
43	1710200-14-5-7	SCREW, CAP HEAD M4	1
44	S102731	SET SCREW M8 X 1.25 - 10mm LONG	1
45	1710200-15-18	SCREW - PHILLIPS HEAD M6-1.0*8mm	2
46	1710200-17-2	SCREW - BUTTON HEAD M5-0.8 X 25mm	4
47	1710200-11-7	GASKET, MOTOR-DRUM SUPPORT	2
48	90-42660-3	O-RING, MOTOR BOLT	2
49	1710200-14-6	BALL BEARING, GEARBOX	1
50	90-42660-1	BUSHING, GEARBOX SX	1
51	1710200-12-2	LED DRUM LIGHT	1

